

Damaged implant removal

Challenges and solutions



Tasks

1 Destroyed coupling mechanism

Insert conical extraction bolt (a) in screw head and try to remove screw

2 Broken screw removal procedure

Remove bone around screw and, at the same time, extract the screw with the hollow reamer (**b**)

The debris accumulating inside the tool needs to be removed frequently.

Learning outcomes

- Identify the function of different instruments to aid screw removal
- Remove screw with destroyed coupling mechanism
- Remove broken screw

Take-home message

- · Use undamaged screw driver
- Clean hexagonal coupling mechanism of screw head
- Do not use a power drill

Problem 1

Destroyed hexagonal coupling mechanism of screw head



Č



Intact



Destroyed

Problem 2

Broken screw, screw shaft stuck inside bone



b

